



GENERAL NOTES:

1. Designers Should Contact Their Local Precaster Before Finalizing Alternative Pier Cap Dimensions.
2. Box Column Post-Tensioning Can Run Straight in Pier Cap and Need Not Flare Out to Match Slopes of Pier Cap.

ALTERNATE BOX PIER CAP SEGMENT